



STAINLESS EXTENSION

FOR MODEL 18C

Get 5 more inches of hang distance and more cooking options!

HOW TO SET IT UP

1. Set the wider Extension on the cooker base INDENTATION SIDE DOWN as shown to the right.
2. Set the narrower, inner Heat/Vapor Shield inside the Extension - no orientation.
3. Set the barrel cooker down on the Extension as if it was the base.

INDENTATION SIDE DOWN



ABOUT THE 18C EXTENSION

1. Always use both parts!
The inner Heat/Vapor Shield keeps heat in and directs water vapor back into the cooker.
2. The cooker will function normally and the extra hang distance will produce great food and allow for longer cuts of meat.
3. The lower level of the cooker will now be higher off the coals which allows for more cooking options.

Made in the USA with stainless steel.



For help or questions please contact us at 844-508-2665 or sales@barrelhousecooker.com